TIPPMANN®

A-5 RESPONSE™ PARTS LIST

02-29L Hopper Left Side
02-30 Hopper Lid
02-34 Hopper Lid Spring
02-29R Hopper Right Side
02-31 Hopper Screws (7)
02-15 Front Sight
TA01101 Receiver Right Black
98-20 Rear Sight Spring
02-39 A-5 Barrel
9-PA Receiver Nut
02-27 Rear Sight
FA-18 Ball Latch
PL-42D 1/4-20 Nut
02-40 Barrel O-ring
02-28
TA01100 Receiver, Left Black
SL2-4 Front Bolt O-ring
02-73 Tombstone Latch
02-13 Cocking Handle
98-01A Receiver Bolt (6) (Short)
02-69 Barrel Adapter
TA10053 Receiver O-Ring
02-17 Front Bolt
02-20S Spring (Red)
TA01016 Linkage Arm
02-14 Cocking Handle Spring
02-22 Velocity Screw
02-70 Name Plate
02-21 Power Tube
02-41 Feeder Housing Bolt
02-38 Trigger Guard
02-02R Lower Receiver Right
02-24 Tombstone Adapter
02-07 Front Grip
TA10058 Interior Flow Connector Fitting
FA-07 Cylinder Fitting O-Ring
02-Push Pin (4)
9-PA
98-45 Flat Washer
02-81 Cylinder Fitting
CA-40 Front Grip Bolt
18-PA O-Ring
PL-42A Screw
02-09 Gas Line
98-55 Safety O-ring Red
02-37 Safety
02-82 Cylinder Fitting Gasket
02-02L Lower Receiver Left
20-02N RT Cylinder
98-01B Receiver Bolt Long
TA10025 Gas Line Elbow
02-06 Tank Adapter

INTERNAL VALVE PARTS
- 02-72 Valve O-ring Large
- 02-71 Valve Washer
- PA-32 Valve Spring
- 98-PL Valve Plunger
- CA-27 Valve Seat
- SL2-25 Valve O-ring Small
- 02-25 Valve Body

WARNING

DO NOT DISASSEMBLE THIS MARKER WHILE IT IS PRESSURIZED WITH AIR. DO NOT PRESSURIZE A PARTIALLY ASSEMBLED MARKER.

PL-42A Screw
02-48 Feeder Screw,Washer
TA10036 Upper Sprocket
TA10035 Lower Sprocket
02-43 Cyclone™ Feeder Housing
02-52L Ratchet Pin (Long)
02-52S Ratchet Pin (Short)
TA01260 Rachet Spring
02-51 Rachet Spring Guide
02-53 Ratchet
02-49 Feeder Axle
02-64 Cylinder Plug
02-66 Cylinder Spring
02-63 U cup Seal
SL2-6 Cylinder Reset O-ring
02-50 Feeder Rachet Spring
02-54 Cylinder Piston
PL-42A Screw
02-65 Feeder Reset Rod
02-44 Feeder Bottom Plate
02-42 Feeder Housing Nut
02-62 Feeder Cylinder
02-61 Reset Button
98-12A Valve/Rear Bolt O-ring (2)
02-V Valve Complete
02-11 Rear Bolt
TA01010 Rear Bolt Plug
02-36 Trigger
02-20S Trigger Spring Red
02-33 Trigger Plate Pin (4)
CA-14 Drive Spring
CA-15 Guide Pin
98-19 Trigger Slider Pin (2)
02-33A Sear Pin (Black)
TA01014 Buffer Washer
02-35 Sear
02-67R Right Trigger Plate
TA01015 End Cap
02-20 Sear Spring (Blue)
98-18 Trigger Slider
02-67L Left Trigger Plate
02-20 Slider Spring (Blue)

RIGHT TRIGGER PLATE WITH PARTS SHOWN IN POSITION

02-20S Spring (Red)
02-33A Sear Pin (Black)
02-35 Sear
02-20 Sear Spring (Blue)
98-19 Trigger Slider Pins
02-33 Pins (4)
02-67R Right Trigger Plate
98-18 Slider
02-36 Trigger
(02-20 Slider Spring Blue -not visible)
02-67L LeftTrigger Plate

20-07 Banjo T Fitting
20-18 Cylinder Hose
20-07 Banjo Fitting
02-20 Banjo Fitting
02-103 Flow Control
TA010-26 Hose1/8"
02-84 O-Ring
TA01060 Flow Control Adapter

REV 01/24/2009