

NUMMECH PRODUCTS

DROP FORWARD FOR N-MAG GRIP FRAME

This drop-forward mount is intended to mimic the N-Mag grip frame's "pseudo-hoseless" bottomline mounting system. Please read these instructions before your installation.

Installation:

1. Remove your marker's grip wraps (this allows access to the bottomline screws).
2. Use an allen key to loosen the ASA's mounting screws from within the empty grip frame. Separate the ASA from the grip frame; keep all hardware as it will be re-used with the new drop-forward.
3. Install the new drop-forward onto the marker's grip frame. Be sure an o-ring is installed within the small o-ring groove located in the upper surface of the drop-forward (see diagram below). Spare o-rings are included with the drop-forward if needed.
4. Install the N-Mag ASA adapter onto the drop-forward. Again be sure an o-ring is installed within the small o-ring groove located on the top of the ASA (see diagram below).
5. Use the two pairs of new screws to attach the ASA. The new ASA screws should stick out the drop-forward's underside by an equal distance, therefore the longer screws are installed behind the shorter screws. Again see the diagram below for locations.
6. Once complete, be sure to test out the pressure connection using your HPA tank. If you hear any leaks coming from the drop-forward's o-rings, the o-ring may have been damaged during assembly and would need to be replaced.

