



THIS DIAGRAM ILLUSTRATES THE O-RINGS RESPONSIBLE FOR AIR LEAKING FROM INSIDE THE FACE OF THE BOLT.

SHOCKER RSX
DOWN BARREL LEAK GUIDE