



Custom Products
Come and get it
Rake Sling

Installation Instructions:

- Remove old trigger from EGO grip frame.
- Place a small amount of grease on spacer and bearing to help hold spacer in place during installation.
- Insert trigger into grip frame.
- Take 1/8" x 5/8" dowel pin and insert into grip frame.
- Press or tap dowel pin into grip frame and trigger bearing.
- Be sure that the dowel pin is lined up with spacer hole and bearing hole before fully inserting dowel pin.

Features Include:

- Ergo design which promotes more comfortable hand positioning.
- Bearing action for reduced friction and faster rate of fire.
- Slimmer trigger design for quicker finger movement.

EGO Trig
install manual
www.CustomProducts.us

The bottom section of the page contains the Custom Products logo, a list of installation instructions, a list of features, and the EGO Trig install manual logo and website address.